MOVIE THEATRE
Popcorn Maker

SmartPlanet

MTP-1

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE REFERENCE.

CONGRATULATIONS

You are now the proud new owner of a SMART PLANET Movie Theatre Popcorn Popper model no. MTP-1

Before using it for the first time, kindly take time to carefully read your instruction manual. Please observe all safety precautions and follow operating procedures. After reading, kindly store your instruction manual in a safe place for future reference. If you pass this Popcorn Popper to a third party, please include the operating instruction manual as well.

PARTS DESCRIPTION

A. Popcorn Cover

B. Popcorn Chute

C. Base

D. On/Off Switch

Electrical Specifications

VOLTAGE	FREQUENCY	WATTAGE
120 V	60Hz	1000 W

ELECTRICITY PRECAUTIONS

- Do not operate any appliance with a damaged cord or plug.
- To protect against electric shock, do not immerse cord, plugs, or other electric parts in water or other liquids.
- Do not use this appliance outdoors.
- After popping, unplug cord from wall outlet.
- Do not leave the appliance plugged in when it is not being used.
- Always unplug the appliance from outlet before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
- A popper that is plugged into an outlet should not be left unattended.
- A short power cord is provided with this appliance to reduce the risk of entanglement or tripping. While we do not recommend it, extension cords are available and may be used if care is exercised in their use. If an extension cord is used, ensure that the marked electrical rating of the extension cord is equal to or greater than the appliance. If the plug is of the grounded type, the extension cord must be a grounding type 3-wire cord. To avoid pulling, tripping or entanglement, position the extension cord so that it does not hang over the edge of the counter, table or other area where it can be pulled on by children or tripped over.

IMPORTANT SAFEGUARDS

To reduce the risk of personal injury or property damage when using the Popcorn Popper, basic safety precautions including the following should be followed:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Always use hot pads or oven mitts. Cover becomes hot during operation.
- To protect against fire, electric shock and injury, do not immerse cord, plug or the appliance in water or other liquid.
- Close supervision is necessary when the appliance is used by or near children.
- Before use, unwind the power cord completely and keep the cord away from the hot parts of the appliance.
- Do not let the power cord hang over edge of the table or counter or touch hot surfaces.
- Do not place the appliance on or near hot gas or electric burner, or in a heated oven.
- Do not operate the appliance with a damaged cord or plug, after the appliance malfunctions, or has been damaged in any manner. Contact Smart Planet Customer Service for examination, repair or adjustment.
- Do not attempt to repair the appliance yourself.
- The use of non recommended accessory attachments may result in fire, electric shock or injury.
- Always unplug the appliance from the electrical outlet when not in use and before cleaning to avoid accidental electrical shock. Allow it to cool before putting on or taking off parts and before cleaning.
- As long as the appliance is hot, even if unplugged, there is the danger of getting burned. Do not touch the appliance and do not place it into storage while hot.
- Do not use the appliance for other than the intended use.
- Please read electric specification stated on page 1. Use a socket with a good ground connection. Do not use two way adapter on the three prong power cord provided.
- For interior household use only. Do not use the appliance outdoors.
- Always turn the unit away from you and place on a flat, dry surface so that residual hot oil or steam will not cause a burn.

To avoid overheating,
add popcorn kernels before operating.

CAUTION

To prevent burns or other personal injuries to children, read and follow all instructions and warning.

PRECAUTIONS FOR USE AROUND CHILDREN

- Close supervision is necessary when this appliance is used near children.
- Do not allow cord to hang over any edge where a child can reach it. Arrange cord to avoid pulling, tripping or entanglement.

BEFORE USING THE FIRST TIME

- Wash the appliance cover in warm, soapy water, rinse thoroughly and dry.
- Wipe the exterior of the appliance base and popcorn chute with a soft, damp cloth and dry.

Note: DO NOT immerse the appliance base in water or any other liquid.

DO NOT put the appliance base into the dishwasher. This will permanently damage the product and will void the warranty

USING YOUR POPCORN POPPER

This popper uses hot air to pop the corn. DO NOT place anything other than popcorn kernels into the popping chamber.

Place popper base on a flat, dry surface.

Preparing popcorn:

1. Remove the cover. Ensure that the vents are clear of popcorn pieces before each use. Use a standard measuring cup (please see the Chart for more info).
2. Pour popcorn kernels into the popping chamber. **DO NOT put oil, butter, shortening, salt, or anything other than popcorn kernels into the chamber.**
3. Place a 4 quart, or larger, heat-resistant bowl below the popcorn chute to collect popcorn as it pops.
4. **Plug the cord into a 120 volt, AC outlet ONLY**. With the cover in place, press the "ON/OFF" switch to the "on" position, toward the " I " symbol.
5. Popcorn will begin to pop, and the cycle will be done within 3 - 4 minutes. After popcorn has completed popping, turn the "ON/OFF" switch to the off position, the " O " symbol. **Popcorn cycle has completed when there is a gap of 5 seconds between kernels popping.** Unplug the popper from the outlet. Let the popper sit, with the lid and measuring/butter cup in place, for at least one minute after completion of the popping cycle. Unpopped kernels may still pop unexpectedly. Use caution when handling the popcorn popper, it will be hot after popping cycle. Always use hot pads or oven mitts to handle hot appliances.

6. If you wish to pop more batches of popcorn immediately, remove any unpopped kernels and loose popcorn from the popper by inverting the popper. Use oven mitts or hot pads when handling the hot popper.

7. A small amount of smoke and/or odor may occur upon heating due to the release of manufacturing oils. This is normal.

DO NOT PLACE POPPER BASE, COVER OR CORD IN AN AUTOMATIC DISHWASHER.

POPCORN SERVING CHART

MEASURE	SERVING
1/4 CUP (4 TABLESPOONS)	**1 PERSON**
1/2 CUP (8 TABLESPOONS)	**2 PEOPLE**
3/4 CUP (12 TABLESPOONS)	**3 PEOPLE**
1 CUP (16 TABLESPOONS)	**4 PEOPLE**

HELPFUL HINTS

- Always use fresh popcorn kernels. Dried out, stale, or old popcorn pops poorly as it has lost its moisture content and may scorch.

- Premium and gourmet popcorns do not yield results as good as regular popcorn. If premium or gourmet popcorn is used, you may notice an increase in the number of unpopped kernels.

- This popper pops using hot air. It does not require any oils or fats to pop the corn, and they should never be used in the popper. **DO NOT use microwave popcorn.**

- If popcorn does not pop, it is usually the result of environmental factors such as the freshness and moisture content of the popcorn, or variances by popcorn type. Un-popped kernels do not necessarily indicate a defect in the appliance.

CLEANING YOUR POPCORN POPPER

Your popcorn popper may be cleaned after every use.

Note: Do not immerse the popper base in water or any other liquid. Do not use any abrasive cleansers or scrubbers on any part of the popper.

1. Unplug the appliance from the electrical outlet. Allow the entire appliance to cool, with measuring cup in place, before cleaning.

2. Remove the cover from the popper base. Separate the cover and unit. Wash in warm, soapy water. Rinse and dry thoroughly.

3. Use a soft, damp cloth to wipe the exterior of the popper and the popcorn chute.

DO NOT wipe inside the popping chamber. Check during every cleaning that no pieces of popcorn are lodged into the vents; ensure that the vents are clear before each use.

MOVIE THEATRE
Popcorn Maker

Caramel Corn

¼ cup butter
1 cup brown sugar
½ cup light corn syrup
½ cup sweetened condensed milk
½ teaspoon vanilla
5 quarts popped corn

Make popcorn in the Popcorn Popper as listed in the instructions. Combine butter, brown sugar and corn syrup in a heavy saucepan. Cook over medium heat, stirring well. Bring to a boil. Stir in milk. Turn to low heat and stir constantly until the mixture reaches a soft ball stage. Stir in the vanilla. In a large bowl, pour syrup over popped corn. Mix well until all the popcorn is coated.

Chocolate Popcorn Deluxe

½ cup butter
5 cups miniature marshmallows
1 ½ quarts popped corn
1 ¼ cups semi-sweet chocolate chips

Make popcorn in the Popcorn Popper as listed in the instructions. Next step is to melt the butter and marshmallows in a 2-quart saucepan over medium-low heat. Stir until all the ingredients are smooth.

Combine the popped popcorn and all the chocolate chips in a big bowl. Pour marshmallow mixture over the popcorn and - chocolate chips. Make sure all the ingredients are mixed together well. Press into a greased 9X9 pan. Chill until firm. Cut into squares and enjoy.

90 DAY LIMITED WARRANTY

Smart Planet warrants this appliance from failures in the material and workmanship for 90 days from the date of original purchase with proof of purchase, provided the appliance is operated and maintained in conformity with the provided instruction manual. Any failed part of the appliance will be repaired or replaced at Smart Planet's discretion.

This warranty does not cover any damage, including discoloration, to any non-stick surface of the appliance. This warranty is null and void, as determined solely Smart Planet if the appliance is damaged through accident, misuse, abuse, negligence, scratching, shipping or if the appliance is altered in any way.

If you think the appliance has failed or requires service within its warranty period, please email the Popcorn Popper Service Department at service@smartplanet.net for further instructions. Please include a description of the defect along with the date you purchased the product and the original receipt with the original purchase date. A receipt proving the original purchase date will be required for all warranty claims, hand written receipts are not accepted. You may be instructed to return the appliance for inspection and evaluation. Return shipping costs are not refundable. Smart Planet is not responsible for returns lost in transit.

Valid only in USA and Canada

SmartPlanet
www.smartplanethome.com

www.smartplanethome.com
Copyright 2012 Smart Planet Canoga Park:. CA 91304
Popcorn Popper Service Center: service@smartplanet.net
copyright v.20120815

SmartPlanet
www.smartplanethome.com

Check out some of our other great products.

www.smartplanethome.com